LEXMARK INKJET SUPPLIES

Cartridges

Tri-Colour

Return program		15			24			29		37	41			37XL			
		018C2110E			018C1524E			018C1429E		018C2140E	018Y0141E			018C2180E			
Regular	1	15A	19	20	24A	26	27	29A	33	37A	41A	83	35XL	37XLA	43XL	31	40
	018CX781E	018C2100E	01M2619E	018MX120E	018C1624E	010N0026E	010NX227E	018C1529E	018CX033E	018C2160E	018Y0341E	018LX042E	018C0035E	018C2200E	018YX143E	018C0031E	018Y0340E
Printer																	
Pro Series — Lexmark X4875, X4975, X6575, X7675											205[1]				500[1]		125[3]
Pro Series — Lexmark X9575											210[1]				500[1]		125[3]
Photo Printers — Lexmark P315, P450									60[3]				140[3]				
Photo Printers — Lexmark P350															110[3]		
Photo Printers — Lexmark P700, P3100 Series			260[2]	450[2]													
Photo Printers — Lexmark P910, P4000, P6000 Series									190[2]				450[2]			125[3]	
Multifunction Printers — Lexmark X70, X73, X80 Series				450[2]													
Multifunction Printers — Lexmark X72, X74, X75, i3						275[2]	140[2]										
Multifunction Printers — Lexmark X125				450[2]													
Multifunction Printers — Lexmark X1100, X1200 Series, X2550						275[2]	140[2]										
Multifunction Printers — Lexmark X1270						275[2]	220[1]										
Multifunction Printers — Lexmark X2300, X2400, X3400 Series	200[2]																
Multifunction Printers — Lexmark X3500, X4500 Series					185[1]								500[1]			125[3]	
Multifunction Printers — Lexmark X2470	120[1]																
Multifunction Printers — Lexmark X2500 Series								150[1]					500[1]			125[3]	
Multifunction Printers — Lexmark X2620, X2650, X2670 *NEW*		150[1]														125[3]	
Multifunction Printers — Lexmark X3300, X5200 Series									190[2]				450[2]			125[3]	
Multifunction Printers — Lexmark X3650, X4650										150[1]				500[1]		125[3]	
Multifunction Printers — Lexmark X4250, F4270			260[2]	450[2]													
Multifunction Printers — Lexmark X4270			260[2]	450[2]													
Multifunction Printers — Lexmark X4800, X4900, X6500 Series											205[1]				500[1]		125[3]
Multifunction Printers — Lexmark X5070, X5075								150[1]					500[1]			125[3]	
Multifunction Printers — Lexmark X5470									280[1]				500[1]			125[3]	
Multifunction Printers — Lexmark X5490, X5495								150[1]					500[1]			125[3]	
Multifunction Printers — Lexmark X5100, X6100 Series												450[2]					
Multifunction Printers — Lexmark X5650, X6650										150[1]				500[1]		125[3]	
Multifunction Printers — Lexmark X6170												285[2]					
Multifunction Printers — Lexmark X6570											205[1]				500[1]		125[3]
Multifunction Printers — Lexmark X7100, X7300, X8300 series									190[2]				450[2]			125[3]	
Multifunction Printers — Lexmark X7350																	
Multifunction Printers — Lexmark X9350															500[1]		125[3]
Printers — Lexmark Z33, Z34, Z35, Z510, Z600 Series						275[2]	140[2]										
Printers — Lexmark Z40 Series, Z51, Z52, Z53, Z54se				450[2]													
Printers — Lexmark Z55, Z65 Series												450[2]					
Printers — Lexmark Z705			260[2]	450[2]													
Printers — Lexmark Z730 Series	200[2]																
Printers — Lexmark Z800 Series									190[2]				450[2]			125[3]	
Printers — Lexmark Z845								150[1]					595[1]			125[3]	
Printers — Lexmark Z1300 Series								150[1]					500[1]			125[3]	
Printers — Lexmark Z1400 Series					185[1]								560[1]			125[3]	
Printers — Lexmark Z1500 Series											210[1]				500[1]		
Printers — Lexmark Z2320 Series		150[1]														125[3]	
Printers — Lexmark Z2420 series										150[1]				500[1]		125[3]	

Cartridges

Mono

Mono XL

Return program	14			23	28		36	42							36XL	
	018C2090E			018C1523E	018C1428E		018C2130E	018Y0142E							018C2170E	
Regular	14A	16	17	23A	28A	32	36A	42A	48	50	70	71	82	34XL	36XLA	44XL
	018C2080E	010N0016E	010NX217E	018C1623E	018C1528E	018CX032E	018C2150E	018Y0342E	017G0648E	017G0050E	012AX970E	015MX971E	018L0032E	018C0034E	018C2190E	018Y0144E
Printer																
Pro Series — Lexmark X4875, X4975, X6575, X7675								220[1]								500[1]
Pro Series — Lexmark X9575								220[1]								485[1]
Photo Printers — Lexmark P315, P450																
Photo Printers — Lexmark P350																
Photo Printers — Lexmark P700, P3100 Series									225[2]	410[2]						
Photo Printers — Lexmark P910, P4000, P6000 Series						200[2]								475[2]		
Multifunction Printers — Lexmark X70, X73, X80 Series											600[2]	225[2]				
Multifunction Printers — Lexmark X72, X74, X75, i3		410[2]	205[2]													
Multifunction Printers — Lexmark X125											600[2]	225[2]				
Multifunction Printers — Lexmark X1100, X1200 Series, X2550		410[2]	205[2]													
Multifunction Printers — Lexmark X1270		410[2]	205[2]													
Multifunction Printers — Lexmark X2300, X2400, X3400 Series																
Multifunction Printers — Lexmark X3500, X4500 Series				215[1]										550[1]		
Multifunction Printers — Lexmark X2470																
Multifunction Printers — Lexmark X2500 Series					175[1]									550[1]		
Multifunction Printers — Lexmark X2620, X2650, X2670 *NEW*	175[1]															
Multifunction Printers — Lexmark X3300, X5200 Series						200[2]								475[2]		
Multifunction Printers — Lexmark X3650, X4650							175[1]								500[1]	
Multifunction Printers — Lexmark X4250, F4270											600[2]	225[2]				
Multifunction Printers — Lexmark X4270											600[2]	225[2]				
Multifunction Printers — Lexmark X4800, X4900, X6500 Series								220[1]								500[1]
Multifunction Printers — Lexmark X5070, X5075					175[1]									550[1]		
Multifunction Printers — Lexmark X5470						350[2]								550[1]		
Multifunction Printers — Lexmark X5490, X5495					175[1]									500[1]		
Multifunction Printers — Lexmark X5100, X6100 Series													600[2]			
Multifunction Printers — Lexmark X5650, X6650							175[1]								500[1]	
Multifunction Printers — Lexmark X6170													600[2]			
Multifunction Printers — Lexmark X6570								220[1]								500[1]
Multifunction Printers — Lexmark X7100, X7300, X8300 series						200[2]								475[2]		
Multifunction Printers — Lexmark X7350						295[1]								580[1]		
Multifunction Printers — Lexmark X9350																540[1]
Printers — Lexmark Z33, Z34, Z35, Z510, Z600 Series		410[2]	205[2]													
Printers — Lexmark Z40 Series, Z51, Z52, Z53, Z54se											600[2]	225[2]				
Printers — Lexmark Z55, Z65 Series													600[2]			
Printers — Lexmark Z705									225[2]	410[2]						
Printers — Lexmark Z730 Series																
Printers — Lexmark Z800 Series						200[2]								475[2]		
Printers — Lexmark Z845					175[1]									565[1]		
Printers — Lexmark Z1300 Series					175[1]									500[1]		
Printers — Lexmark Z1400 Series				215[1]										510[1]		
Printers — Lexmark Z1500 Series								220[1]								500[1]
Printers — Lexmark Z2320 Series	175[1]															
Printers — Lexmark Z2420 series						175[1]									475[1]	

Photo paper

	PerfectFinish™ Photo paper			Premium Photo paper				Photo paper	
	0019Y0190	0019Y0200	0019Y0205	0021G0710	0021G0711	0080D1707	0021G0709	0080D1706	0021G0708
Size	10 x 15 cm	10 x 15 cm	A4	10 x 15 cm	10 x 15 cm	A4	A4	A4	A4
Sheet count	50 sheets	100 sheets	50 sheets	20 sheets	60 sheets	15 sheets	50 sheets	20 sheets	50 sheets
Weight	255 g	255 g	255 g	240 g	240 g	240 g	240 g	190 g	190 g

Multi packs

	Combo packs						Twin packs		
	16+26	17+27	23+24	28+29	32+33	43XL+44XL	1+1	17+17	32+32
	0080D2126	0080D2952	018C1419E	018C1520E	0080D2951	0080D2966	0080D2955	0080D2954	0080D2956
Colour	CMYK	CMYK	CMYK	CMYK	CMYK	CMYK	CMY	K	K
Return Program	No	No	Yes	Yes	No	No	No	No	No

(1): Up to this number of standard pages according to ISO/IEC 24711. Actual yield may vary according to customer usage
(2): Up to this number of pages at 5% coverage for Mono and 15% coverage for tri-colour. Actual yield may vary according to customer usage
(3): Up to this number of 10x15 pages printed on photo paper. Actual yield may vary according to customer usage
(4): Photo cartridge with Black, Light Cyan and Light Magenta inks. Prints only when associated with a tri-colour cartrdige.